# Connecting the grandMA to WYSIWYG

#### Configuring the grandMA1 (MA-Net 1)

- 1. Power up the grandMA console, or run the grandMA onPC software.
- 2. Click the Tools button. The Tools Menu window appears.
- 3. Click the DMX & NSP Configuration button. In the WYSIWYG Config window, ensure the following:
  - a. The WYSIWYG Output & Autofocus button reads 'Enabled'.
  - b. A number between 1 and 31 is shown as the Connection ID (MA Session ID). Please remember this number, because you will need it when you set up the connection in WYSIWYG driver. If you are running multiple consoles, they must each have a unique Connection ID.

There must be an active MA Session in order to transmit DMX data to WYSIWYG. (look at step 5d, below)



- 4. Once all the settings are confirmed, hit the Save button, and then the X next to it, to close the DMX Configuration window.
- 5. Back in the Tools Menu window, click the MA Network button.
  - a. Enter *one of the following* in the Station IP Address field. Please remember what you enter here: you will need this IP address in order to configure the grandMA WYSIWYG driver.

If WYSIWYG and grandMA onPC are running on the same computer, you must enter the same IP address as in step 2 of the driver configuration (below), e.g. 127.0.0.1. In any other case (i.e. grandMA onPC is running on a different computer on the network than WYSIWYG, or you are using an actual grandMA console connected to the network the WYSIWYG computer is on), the IP address must be in the same subnet as the computer with WYSIWYG. For example, if your WYSIWYG computer's IP address is 192.168.1.20, the IP address 192.168.1.21 should work for your console, as long as no other device on your network is using that same address.

b. A number between 1 and 31 is entered in the MA Session ID field. The MA Session ID is equivalent to the WYSIWYG Connection ID. Please remember this number, because you will need it when you set up the connection in WYSIWYG. If you are running multiple consoles, they must each have a unique Connection ID.

Screen1 Screen2 Screen3 grand MA on PC Keybrd Backgrd Tools S	Setup Backup	VwPool	Delete	Сору	Move	Oops	CMD. ShortCut
MA Network - Consoles Idle	×	Tim Man	View	Effect	Goto	Assign	B.O.
Active Network Sessions Stations in Network Session	Consoles	ΞΙΞ	Page	Macro	Preset	Help	<b>1</b>
Unconnected I tm Standalo 127.0.0.1(100)		ΞΞ	Sequ.	Cue	Exec.	Align	ΞΞ
			Channel	Fixture	Group		ΞΞ
	3D	Channel	100 M		Contraction of the local		1
	Video	Preview	7	8	9	+	Escape
My Station My Session	• NDP	Blind	4	5	6	11-	Time
IP-Address 127.0.0.1(100) ID b 10	• 2 Dort	Freeze	1	2	3	Thru	Update
Prioritiy Normal Password		10-00	111.	0	Īf	Āt	Edit
Invitation Enabled Style Multiuser	Remotes	Clear	Highlight	Full/Open	En	ter	Store
Local Station Start Join Leave Session Session Session Session Stations Stations		NAVIG	D			VEL	
1 2 3 4 5 6 7 8	9 10	Fix	Select	Off			
		Temp	Тор	- On		Up	
E E± EE EE E =  EE EE EE EE	EEE		Learn	>>>	Prev.	Set	Next
		Go-	- Pause	Go+		Down	
		Ch 1-10	Ex 1-10	Ex Btn		-	-
PgDn		Ch 11-20	Ex 11-20	Encoder	Pause	Go	Go+

- c. The session style must be Full Tracking or Multiuser.
- d. Hit the Button 'Start New Session' to start a MA session.

- 6. Close the MA Network Connections window by clicking on the X in the upper right hand corner, and then close the Tools Menu window the same way.
- 7. Patch the console, ensuring that the patch matches the WYSIWYG show file. You do not need to assign position information to fixtures.

# Configuring the grandMA2 (MA-Net 2)

- 1. Power up the grandMA2 console, or run the grandMA2 onPC software.
- 2. Click the Setup button. The Setup Menu window appears.
- 3. Click the Console Tab and then Global Settings Button.
- 4. Ensure that Wysiwyg Enabled is On.

SetUp Software V 1.3.15 Setup/Console/Global Sett	SetUp Software V 1.3.15 Show 'wygtest 2009-08-20' User 'Guest' Setup/Console/Global Settings						
Show	Console	User	Network				
Desk Lights	Agenda Stopped		Off On				
Screen Options	Wysiwyg Enabled		Off On				
Global Settings							
Faders	Þ						
Date & Time	Þ						
Software Update	Þ						
Fixture Library Managemer	nt¢						
User+Profiles Setup	Þ						

- 5. Click the Network Tab and then MA Network Control Button.
  - a. A number between 1 and 31 is entered in the Session ID field. The Session ID is equivalent to the WYSIWYG Connection ID. Please remember this number, because you will need it when you set up the connection in WYSIWYG. If you are running multiple consoles, they must each have a unique Connection ID.
  - b. Enter *one of the following* in the Station IP Address field. Please remember what you enter here: you will need this IP address in order to configure the grandMA WYSIWYG driver.

If WYSIWYG and grandMA2 onPC are running on the same computer, you must enter the same IP address as in step 2 of the driver configuration (below), e.g. 127.0.0.1.

In any other case (i.e. grandMA2 onPC is running on a different computer on the network than WYSIWYG, or you are using an actual grandMA console connected to the network the WYSIWYG computer is on), the IP address must be in the same subnet as the computer with WYSIWYG. For example, if your WYSIWYG computer's IP address is 192.168.1.20, the IP address 192.168.1.21 should work for your console, as long as no other device on your network is using that same address.

MA-Net Control Standalone 🗙								
Sessions		Stations						
Id Name		IP	Status		Name	Version	Туре	
Unconnected		127.0.0.1	Standalon	e	Thomas	1.3.15	Console	
Session Id:	ı	10		Stati	on IP: b		127.0.0.1	
Session Name:		S1		Stati				
Session Password:				Stati	on Master Prio.:		Normal	
_				Stati	on Invitation:		Enabled Disabled	
Join Leave Session Sessio					Invite Station	Dismiss Station		
c								

c. Hit the Button 'Join Session' to start a MA session.

MA-	Net Control				Master	· X	
	Sessions			Stations			
Id	Name	IP	Status	Name	Version	Туре	
10	Unconnected S1	127.0.0.1	Master	Thomas	1.3.15	Console	
Sess			Sta			127.0.0.1	
Sess		S1	Sta				
Sess			Sta			Normal	
			Sta	ation Invitation:	l	Enabled Disabled	
Joir Ses	n Leave ssion Session			Invite Station	Dismiss Station		

### Installing and Configuring the grandMA WYSIWYG Driver

The grandMA WYSIWYG driver must be installed in order to establish a connection between the grandMA console and WYSIWYG. Installation is straight-forward: simply double-click on gMA-Wysiwyg[Xxxx][Xxxx]-vXxxx.exe and follow the on-screen instructions. Once installation is complete, you will notice an addition to your Control Panels, "grandMA – WYSIWYG Driver".

Steps to configuring the driver:

- 1. Double-click on the grandMA WYSIWYG Driver icon in your Control Panel.
- 2. Choose the MA-Net Mode (MA-Net2 corresponds with the grandMA2 range).
- 3. Select an IP Address which is in the same subnet as the one for the console in step 5 of the console configuration (above).

grandMA - WYSIWYG driver opt	ions 🔹 👔
MA-Net Mode:	× 🖬 🖬
MA-Net2	• V~
Station IP Address:	grandMA - WYSIWYG Autofocus driver
MA Session IDs: grandMA 1: 10 • grandMA 2: •	Vers. 1.410-6.200-v1.000 Copyright © 2009 by MA Lighting Technologies
grandMA 3:	OK Cancel

- a. Enter the MA Session ID (which you set in step 5, above) to the corresponding connection name and remember the connection name, because you will need it when you set up the connection in WYSIWYG. The numbers <u>must</u> match, or a connection cannot be established.
- 4. Click OK.

## **Configuring WYSIYWG and Connecting to the Console**

Before attempting the connection described below, please ensure the following:

- The grandMA onPC application is running, and is configured as described at the beginning of this document. If you are using a physical grandMA console, please make sure that it is powered up and connected to the network to which the WYSIWYG computer connected. It should also be mentioned here that when patching fixtures on the grandMA, you do not need to assign position information (i.e. X, Y, Z coordinates) to them. (Of course, you still have the option to do so if you wish.)
- The proper patch universes are defined in your WYSIWYG show, and that your fixtures are patched. In addition, all your fixtures have the proper Spot Numbers assigned, matching what you have in the console. (Spot Number in WYG = FixtureID on the grandMA)

Follow these steps to connect to the grandMA:

- 1. Load the show file and switch to LIVE Mode.
- 2. Go to the Live menu, and select Device Manager.
- 3. Click the New button.
- 4. Expand the Consoles tree (if it is not already expanded), then the MA Lighting tree and click on the grandMA to select it. Click the Insert button. The grandMA is now listed in the Device Manager.
- 5. With the Grand MA selected, click the Properties button. The console's Properties window appears.
- 6. Ensure the following:
  - a. The console's Connection Name (above) is entered in the Address field.
  - b. The console's outputs are bound to the appropriate WYSIWYG Patch Universes. (Patch A on the console is Output 1 in WYG, Patch B on the console is Output 2 in WYG, and so on.)

Properties		<u>? ×</u>
Console		
Manufacturer		Open
Model : Grand MA		Bind
Name : gMA 1		UnBind
Address grandMA 1	1	
Ports	Universe	Chans
Ports Dutput 1 Output 2	Universe SC SS	Chans
Ports Output 1 Output 2 Output 3 Output 4	Universe SC SS DIM None	Chans
Ports Output 1 Output 2 Output 3 Output 4 Output 5 Output 6 Output 7	Universe SC SS DIM None None None None	Chans
Ports Output 1 Output 2 Output 3 Output 4 Output 5 Output 6 Output 7 Output 8	Universe SC SS DIM None None None None None	Chans
Ports Output 1 Output 2 Output 3 Output 4 Output 5 Output 5 Output 6 Output 7 Sutput 8	Universe SC SS DIM None None None None None	Chans

- 7. Click OK.
- 8. Back in the Device Manager window, please ensure that the AF icon appears next to the console. This icon tells you which console AutoFocus is bound to. Please note that AutoFocus may only be bound to one console at a time.

vice Manager				?
)evice Manager				
Name	Туре	Status	Connect on load	New
AB gMA 1	Grand MA	Not Connected	No	Broperties
MA 2	Grand MA	Not Connected	No	
gMA 3	Grand MA	Not Connected	No	Delete
				Connect
				Select All
Unbind AutoFocus				Connect on load
				Close

If you are using multiple consoles for your show, follow these steps in order to switch the AutoFocus binding between them:

- a. Select the console with AutoFocus bound to it.
- b. Click the Unbind AutoFocus button at the bottom of the window.
- c. Select the next console.
- d. Click the Bind AutoFocus button at the bottom of the window.

vice Manager				?
)evice Manager				
Name	Туре	Status	Connect on load	New
AB gMA 1	Grand MA	Not Connected	No	Properties
gMA 2	Grand MA	Not Connected	No	Fiopenies
gMA 3	Grand MA	Not Connected	No	Delete
				Connect
				Select All
Bind AutoFoc	us			Connect on load
				Close

- e. The AF icon will appear next to the selected console, as before.
  Click the Connect button. The Status of the selected console changes to `Connected'.
- 9. Click the Close button in the bottom right hand corner.
- 10. Turning fixtures on from the console should display their beams in WYSIWYG's LIVE Mode.
- 11. In order to use AutoFocus, in LIVE Mode, go to the Live menu, and select the Designer Tools you want/need to use.
- 12. Select fixtures in WYSIWYG (you must create Concepts in order to select fixtures in full Shaded View), and click the Full button on the Intensity Tool: you should now see their beams in WYG. Clicking and dragging inside the trackpad in the Focus Tool should move the beams around (if you are using moving head/mirror fixtures). Colour selection only works for fixtures that support colour mixing. The Iris Tool only affects fixtures that have an iris.

Happy programming!